

Type 8041

Insertion electromagnetic flowmeter

Magnetisch-induktives Durchfluss-Messgerät, Insertion

Débitmètre électromagnétique à insertion



Operating Instructions

Bedienungsanleitung

Manuel utilisateur

We reserve the right to make technical changes without notice.
Technische Änderungen vorbehalten.
Sous réserve de modifications techniques.

© Bürkert SAS, 2011 - 2013

Operating Instructions 1308/1_EU-ML_559777_Original_FR

1. ABOUT THIS MANUAL.....	3	6.4. General data	11
1.1. Symbols used	3	6.5. Electrical data	12
1.2. Definition of the word "device"	3	6.6. Electrical connections	13
2. INTENDED USE.....	4	6.7. K factors.....	13
3. BASIC SAFETY INFORMATION	4	7. QUICK INSTALLATION	14
4. GENERAL INFORMATION.....	6	8. INSTALLATION.....	16
4.1. Manufacturer's address and international contacts.....	6	8.1. Safety instructions.....	16
4.2. Warranty conditions.....	6	8.2. Installation onto the pipe.....	17
4.3. Information on the Internet.....	6	8.2.1. Recommendations for installing the 8041 on the pipe.....	17
5. DESCRIPTION.....	6	8.2.2. Installation into the pipe of a 8041 with a G2" nut	20
5.1. Area of application	6	8.2.3. Installation into the pipe of a 8041 with a clamp connection	21
5.2. General description	6	8.3. Wiring.....	21
5.2.1. Construction.....	6	8.3.1. Wiring the 4-20 mA output.....	24
5.2.2. Operating principle.....	6	8.3.2. Wiring the frequency output.....	24
5.3. Description of the name plate	7	8.3.3. Wiring the relay output	26
5.4. Available versions.....	7	9. ADJUSTMENT AND COMMISSIONING	27
6. TECHNICAL DATA.....	8	9.1. Safety instructions.....	27
6.1. Conditions of use.....	8	9.2. Description of the electronic board	28
6.2. Conformity to standards and directives.....	8	9.3. General diagram of the Read and	
6.3. Mechanical data.....	8		

Parameterizing modes.....	30	14. DISPOSAL OF THE DEVICE.....	54
9.4. Selecting the frequency of the main supply	32		
9.5. Filter selection	32		
9.6. Selecting the measurement range.....	33		
9.7. Calibrating the flow zero point	33		
9.8. Calibrating the full scale	36		
9.9. Setting the parameters of the relay output	39		
9.9.1. Choosing the switching way of the relay output.....	40		
9.9.2. Viewing and setting the low and high switching thresholds	42		
9.9.3. Viewing and setting the time delay before switching ..	45		
10. MAINTENANCE AND TROUBLESHOOTING.....	48		
10.1. Safety instructions.....	48		
10.2. Cleaning the device.....	48		
10.3. Cleaning the electrodes	48		
10.4. Replacing the seal on a device with G2 ¹ nut.....	49		
10.5. If you encounter problems.....	49		
11. SPARE PARTS AND ACCESSORIES.....	53		
12. PACKAGING, TRANSPORT.....	54		
13. STORAGE.....	54		

1. ABOUT THIS MANUAL

This manual describes the entire life cycle of the device. Please keep this manual in a safe place, accessible to all users and any new owners.

This manual contains important safety information.

Failure to comply with these instructions can lead to hazardous situations.

- This manual must be read and understood.

1.1. Symbols used



DANGER

Warns against an imminent danger.

- Failure to observe this warning can result in death or in serious injury.



WARNING

Warns against a potentially dangerous situation.

- Failure to observe this warning can result in serious injury or even death.



ATTENTION

Warns against a possible risk.

- Failure to observe this warning can result in substantial or minor injuries.

NOTE

Warns against material damage.

- Failure to observe this warning may result in damage to the device or system.



Indicates additional information, advice or important recommendations.



Refers to information contained in this manual or in other documents.

→ Indicates a procedure to be done.

1.2. Definition of the word "device"

The word "device" used within these operating instructions refers to the flowmeter type 8041.

2. INTENDED USE

Use of the device that does not comply with the instructions could present risks to people, nearby installations and the environment.

- The 8041 flowmeter is intended exclusively to measure the flow rate in liquids.
- This device must be protected against electromagnetic interference, ultraviolet rays and, when installed outdoors, the effects of climatic conditions.
- This device must be used in compliance with the characteristics and commissioning and use conditions specified in the contractual documents and in the operating instructions.
- Requirements for the safe and proper operation of the device are proper transport, storage and installation, as well as careful operation and maintenance.
- Only use the device as intended.

→ Observe any existing restraints when the device is exported.

3. BASIC SAFETY INFORMATION

This safety information does not take into account:

- any contingencies or occurrences that may arise during installation, use and maintenance of the devices.
- the local safety regulations for which the operating company is responsible including the staff in charge of installation and maintenance.



Danger due to high pressure in the installation.

Danger due to electrical voltage.

Danger due to high temperatures of the fluid.

Danger due to the nature of the fluid.



Various dangerous situations

To avoid injury take care:

- to prevent any unintentional power supply switch-on.
- to ensure that installation and maintenance work are carried out by qualified, authorised personnel in possession of the appropriate tools.
- to guarantee a defined or controlled restarting of the process, after a power supply interruption.



Various dangerous situations (cont'd)

To avoid injury take care:

- not to use the device for the measurement of gas flow rates.
- not to use the device in explosive atmospheres.
- not to use the device in an environment incompatible with the materials it is made of.
- not to subject the device to mechanical loads (e.g. by placing objects on top of it or by using it as a step).
- not to make any external or internal modifications to the device.
- to use the device only if in perfect working order and in compliance with the instructions provided in these operating instructions.
- to observe the general technical rules when installing and using the device.

NOTE

The device may be damaged by the fluid in contact with.

- Systematically check the chemical compatibility of the component materials of the device and the fluids likely to come into contact with it (for example: alcohols, strong or concentrated acids, aldehydes, alkaline compounds, esters, aliphatic compounds, ketones, halogenated aromatics or hydrocarbons, oxidants and chlorinated agents).

NOTE

Elements / Components sensitive to electrostatic discharges

- This device contains electronic components sensitive to electrostatic discharges. They may be damaged if they are touched by an electrostatically charged person or object. In the worst case scenario, these components are instantly destroyed or go out of order as soon as they are activated.
- To minimise or even avoid all damage due to an electrostatic discharge, take all the precautions described in the EN 61340-5-1 and 5-2 norms.
- Also ensure that you do not touch any of the live electrical components.

4. GENERAL INFORMATION

4.1. Manufacturer's address and international contacts

To contact the manufacturer of the device, use following address:

Bürkert SAS

Rue du Giessen

BP 21

F-67220 TRIEMBACH-AU-VAL

You may also contact your local Bürkert sales office.

They can also be found on the Internet under:

www.burkert.com

4.2. Warranty conditions

The condition governing the legal warranty is the conforming use of the device in observance of the operating conditions specified in these operating instructions.

4.3. Information on the Internet

You can find the user manuals and technical data sheets regarding the type 8041 at:

www.burkert.com

5. DESCRIPTION

5.1. Area of application

The device is used to measure the flow of neutral or slightly aggressive fluids with a conductivity of more than 20 $\mu\text{S}/\text{cm}$ in DN06 to DN400 pipes.

5.2. General description

5.2.1. Construction

The device comprises an electronic module and a PVDF or stainless steel measurement sensor.

The flow sensor comprises two electrodes and a magnetic system.

The connection of the device to the process is made depending on the version, either by a G2" nut or a clamp.

Electrical connection is made via two cable glands on a 6-pin terminal block.

The device requires an 18-36 VDC power supply and has:

- a frequency output,
- a relay output,
- a 4-20 mA current output.

5.2.2. Operating principle

The magnetic system in the flow sensor generates a magnetic field in the fluid, perpendicular to the flow direction, see [Fig. 1](#). The electrodes on the flow sensor ensure electrical contact with the fluid.

Type 8041

Description

When the fluid flows over them, a voltage is measured between the two electrodes. This voltage is proportional to the fluid velocity.




Fig. 1: Operating principle of the flow sensor

5.3. Description of the name plate




Fig. 2: Name plate of the device (example)

1. Power supply / Max. consumption.
2. Measured value and type of the device
3. Specification of the flow sensor

4. Compact housing
5. Manufacturing code
6. Relay data
7. Conformity logo
8. Warning: Before using the device, take into account the technical specifications described in these operating instructions.
9. Current output
10. Serial number
11. Order code

5.4. Available versions

Flow sensor	Material		Order code
	Flow sensor	Seal of the flow sensor	
Short	PVDF	FKM	558064
Long			558065
Short	Stainless steel	FKM	552779
Long			552780
Clamp	Stainless steel	EPDM or FEP ¹⁾	564688

¹⁾ Ordered separately. See chap. 11.

6. TECHNICAL DATA

6.1. Conditions of use

Ambient temperature	-10 °C...+60 °C
Air humidity	< 80%, non condensated
Protection class acc. to EN 60529	IP65, with cable connected and cable gland tightened and cover screwed on to the electronic module
Degree of pollution	Degree 2 acc. to EN 61010-1
Installation category	Category I acc. to EN 61010-1
Max height above sea level	2000 m

6.2. Conformity to standards and directives

The device conforms to the EC directives through the following standards:

- EMC: EN 50081-1, EN 61000-6-2
- LVD: EN 61 010-1
- Pressure: article 3§3 of the Pressure Directive 97/23/CE. Acc. to the Pressure Directive 97/23/CE: the device can only be used in the following cases (depending on the max. pressure, the DN of the pipe and the fluid)

Type of fluid	Conditions
Fluid group 1, par. 1.3.a	Forbidden
Fluid group 2 par. 1.3.a	DN ≤ 32 or DN > 32 and PNxDN ≤ 1000
Fluid group 1 par. 1.3.b	PNxDN ≤ 2000
Fluid group 2 par. 1.3.b	DN ≤ 200 or PN ≤ 10 or PNxDN ≤ 5000

6.3. Mechanical data

Table 1 : Wetted parts

Part	Material
Holder of the flow sensor	PVDF or stainless steel 1.4404 / 316L
Electrodes	Stainless steel 1.4404 / 316L
Clamp (only clamp version)	Stainless steel 1.4404 / 316L
Earthing ring (only if flow sensor holder in PVDF)	Stainless steel 1.4404 / 316L
Holder of the electrodes (only if flow sensor holder in stainless steel)	PEEK
Seal of the flow sensor (version with G2" nut)	FKM (FDA approved)

Type 8041

Technical data

Table 2 : Parts not in contact with the fluid

Part	Material
Housing, cover, nut	
<ul style="list-style-type: none"> ▪ holder of the flow sensor in stainless steel ▪ holder of the flow sensor in PVDF 	<ul style="list-style-type: none"> ▪ PPA, glass fiber reinforced ▪ PC, glass fiber reinforced
Screws of the cover	Stainless steel
Cable gland	PA
Seal of the cover	EPDM
Seal of the cable gland	Neoprene




Fig. 3: Parts of the flow sensor holder in stainless steel (left) or in PVDF (right), devices with a G2" nut




Fig. 4: Parts of the flow sensor in stainless steel with a clamp connection




Fig. 5: Dimensions of the 8041 [mm]




Table 3 : Dimension H in mm of the flowmeter 8041 with a G2" nut and inserted into an S020 fitting

	 T-fitting	 Saddle	 Spigot, in plastic	 Welding tab with radius, in stainless steel
DN6	163			
DN8	163			
DN15	168			
DN20	166			
DN25	166			
DN32	169			
DN40	173			169
DN50	179	204		174
DN65	179	203	187	180
DN80		207	193	185
DN100		221	200	195
DN110		208		
DN125		215	233	206
DN150		225	242	217
DN180		249		
DN200		261	263	238
DN250			281	298
DN300			293	317
DN350			306	329
DN400			321	

Type 8041

Technical data

Table 4 : Dimension H in mm of the flowmeter 8041 with a clamp connection and inserted into an S020 fitting

		
	T-fitting	Welding socket
DN32	181	181
DN40	186	186
DN50	191	191
DN65	199	199
DN80	205	205
DN100	211	211

6.4. General data

Pipe diameter	DN06 to DN400
Type of fitting	S020
Fluid conductivity	> 20 $\mu\text{S/cm}$

¹⁾ Determined in the following reference conditions: fluid = water, water and ambient temperatures = 20 °C, upstream and downstream distances respected, appropriate pipe dimensions

<p>Fluid temperature</p> <ul style="list-style-type: none"> ▪ with holder of the flow sensor in stainless steel ▪ with holder of the flow sensor in PVDF 	<p>The fluid temperature may be restricted by the fluid pressure and the material of the S020 fitting used (see Fig. 6 and Fig. 7).</p> <ul style="list-style-type: none"> ▪ -15...+150 °C ▪ 0...+80 °C
<p>Fluid pressure</p> <ul style="list-style-type: none"> ▪ with holder of the flow sensor in stainless steel ▪ with holder of the flow sensor in PVDF 	<p>The fluid pressure may be restricted by the fluid temperature, the material of the S020 fitting used and the DN of the S020 fitting used (see Fig. 6 and Fig. 7).</p> <ul style="list-style-type: none"> ▪ PN10 with a fitting in plastic, PN16 with a fitting in metal ▪ PN10
<p>Flow rate measurement</p> <ul style="list-style-type: none"> ▪ Measuring range ▪ Linearity ▪ Repeatability ▪ Accuracy with standard K factor ▪ Accuracy with Teach-in 	<ul style="list-style-type: none"> ▪ 0,2 to 10 m/s ¹⁾ ▪ $\pm 0,5\%$ ¹⁾ of the full scale ▪ $\pm 0,25\%$ ¹⁾ of the measured value ▪ $\pm 3,5\%$ ¹⁾ of the measured value ▪ $\pm 0,5\%$ ¹⁾ of the measured value





Fig. 6: Fluid pressure-temperature dependency of the 8041 with a flow sensor holder in PVDF, inserted into an S020 fitting in metal, PVDF, PVC or PP



¹⁾ Except DN100 for measuring devices with a clamp connection

Fig. 7: Fluid pressure-temperature dependency of the 8041 with a flow sensor holder in stainless steel, inserted into an S020 fitting in metal, PVDF, PVC or PP

6.5. Electrical data

Power supply	18-36 V DC, filtered and regulated
Current consumption	220 mA (at 18 V DC)
Power source (not supplied)	limited energy source (in accordance to UL 61010-1, paragraph 9.3)

Current output <ul style="list-style-type: none"> ▪ Type of output ▪ Accuracy ▪ Refresh time ▪ Max. loop impedance 	<ul style="list-style-type: none"> ▪ 4-20 mA, sinking or sourcing wiring ▪ $\pm 1\%$ (0,16 mA) ▪ 100 ms ▪ 1100 Ω at 36 V DC, 330 Ω at 18 V DC
Frequency output <ul style="list-style-type: none"> ▪ Frequency ▪ Duty cycle ▪ Max current ▪ Protected against short-circuits and polarity reversal 	<ul style="list-style-type: none"> ▪ 0-240 Hz ▪ 50 % $\pm 1\%$ ▪ 100 mA max. ▪ yes
Relay output	<ul style="list-style-type: none"> ▪ Normally open or normally closed, depending on the wiring ▪ 3 A, 250 V AC max.
Alarm <ul style="list-style-type: none"> ▪ Full scale exceeded ▪ Error signal 	<ul style="list-style-type: none"> ▪ 22 mA and 256 Hz ▪ 22 mA and 0 Hz

6.6. Electrical connections

Type of connection	Through two M20x1,5 cable glands
--------------------	----------------------------------

Cable specifications <ul style="list-style-type: none"> ▪ cable type ▪ Cross section ▪ Diameter of each cable: <ul style="list-style-type: none"> - if only one cable is used per cable gland - if two cables are used per cable gland 	<ul style="list-style-type: none"> ▪ shielded ▪ 0,5 to 1,5 mm² - 6...12 mm - 4 mm, with the supplied multi-way seal
---	--

6.7. K factors



The S020 fitting with weld end connections is available in two versions: a version for the measuring devices with a G2" nut and a version for the measuring devices with a clamp connection.

- Use the K factor of the fitting used.

The device measures the flow velocity (in m/s) of the fluid and converts it into a current (in mA) and a frequency rating (in Hz).

The current I or the frequency f are proportional to the flow rate Q (l/s), the proportionality factor is called the "K factor":

$$f = K_1 * Q$$

$$I = K_2 * Q + 4$$

with K_1 and K_2 in pulse/litre

The following formulae are used to calculate the K_1 and K_2 factors needed to convert the current or frequency into a flow rate:

Full scale	K factor K_1	K factor K_2
10 m/s	$K_1 = \frac{100}{K_{\text{fitting}}}$	$K_2 = \frac{20}{3 \cdot K_{\text{fitting}}}$
5 m/s	$K_1 = \frac{200}{K_{\text{fitting}}}$	$K_2 = \frac{40}{3 \cdot K_{\text{fitting}}}$
2 m/s	$K_1 = \frac{500}{K_{\text{fitting}}}$	$K_2 = \frac{100}{3 \cdot K_{\text{fitting}}}$

where K_{fitting} = K factor of the S020 fitting used


Example:

If the full scale of the device is set to 5 m/s, the value of the current output will be:

$$I = \frac{40}{3 \cdot K_{\text{fitting}}} Q + 4$$



with I in mA, K_{fitting} in pulse/litre and Q in l/s.


7. QUICK INSTALLATION



Type 8041

Quick installation





8. INSTALLATION

8.1. Safety instructions



DANGER

Risk of injury due to high pressure in the installation.

- Stop the circulation of fluid, cut off the pressure and drain the pipe before loosening the process connections.

Risk of injury due to high fluid temperatures.

- Use safety gloves to handle the device.
- Stop the circulation of fluid and drain the pipe before loosening the process connections.

Risk of injury due to the nature of the fluid.

- Respect the prevailing regulations on accident prevention and safety relating to the use of aggressive fluids.

Risk of injury due to electrical voltage.

- Shut down the electrical power source of all the conductors and isolate it before carrying out work on the system.
- Observe all applicable accident protection and safety regulations for electrical equipment.

**WARNING****Risk of injury due to non-conforming installation.**

- The electrical and fluid installation can only be carried out by qualified and skilled staff with the appropriate tools.
- Install appropriate safety devices (correctly rated fuse and/or circuit-breaker).

Risk of injury due to unintentional switch on of power supply or uncontrolled restarting of the installation.

- Take appropriate measures to avoid unintentional activation of the installation.
- Guarantee a set or controlled restarting of the process subsequent to any intervention on the device.

**WARNING****Risk of injury if the fluid temperature/pressure dependency is not respected.**

- Observe the fluid temperature/pressure dependency according to the nature of the material of the fitting used (see [Fig. 6](#) and [Fig. 7](#)).


8.2. Installation onto the pipe

8.2.1. Recommendations for installing the 8041 on the pipe

→ Choose a fitting appropriate to the velocity of the fluid inside the pipe; refer to the graphs below:

Example:

- Specification: if the nominal flow rate is $10 \text{ m}^3/\text{h}$ the ideal flow velocity is between 2 and 3 m/s
- Solution: intersection between flow rate and flow velocity in the graph gives the appropriate pipe diameter, DN40 (or DN50 for the asterisked fittings).



*** For the fittings:**

- with external thread connections acc. to SMS 1145 ;
- with weld end connections acc. to SMS 3008, BS 4825 / ASME BPE or DIN 11850 Range 2;
- with Clamp connections acc. to SMS 3017 / ISO 2852, BS 4825 / ASME BPE or DIN 32676.

Type 8041

Installation

→ Install the device on the pipe to have the upstream and downstream distances respected according to the design of the pipes, refer to standard EN ISO 5167-1 and [Fig. 8](#):




Fig. 8: Upstream and downstream distances depending on the design of the pipes.

→ Respect the following additional mounting conditions to ensure that the measuring device operates correctly:

- We recommend to install the device at a 45° angle to the horizontal centre of the pipe to prevent deposits on the electrodes and false measurements due to air bubbles (see [Fig. 9](#));





Fig. 9: Mounting angle on the pipe

- Ensure that the pipe is always filled in the section around the device (see [Fig. 10](#)).
- When mounting vertically ensure that the flow direction is in an upward direction (see [Fig. 10](#)).
- Prevent the formation of air bubbles in the pipe in the section around the device (see [Fig. 11](#)).
- Always mount the device upstream a possible injection point in the pipe of a high-conductivity fluid (for example: acid, base, saline,...).






Fig. 10: Filling of the pipe




Fig. 11: Air bubbles within the pipe

→ If necessary, use a flow conditioner to improve measurement precision.

8.2.2. Installation into the pipe of a 8041 with a G2" nut



Observe the installation recommendations described at chap. 8.2.1 and in the operating instructions of the S020.

- Install the S020 fitting on the pipe.
- Insert the nut (see mark 3, Fig. 12) on the fitting.
- Insert the snap ring (mark 2, Fig. 12) into the groove (mark 5, Fig. 12).
- Position the cable glands parallel to the pipe and insert the device (mark 1, Fig. 12) into the fitting.
- Tighten the nut (mark 3, Fig. 12) by hand on the device.




Fig. 12: Installation into the pipe of the flowmeter with a G2" nut

8.2.3. Installation into the pipe of a 8041 with a clamp connection

! Observe the installation recommendations described at chap. 8.2.1 and in the operating instructions of the S020.

→ Install the S020 fitting on the pipe.




Fig. 13: Installation into the pipe of a 8041 with a clamp connection

8.3. Wiring



DANGER

Risk of injury due to electrical voltage.

- Shut down the electrical power source of all the conductors and isolate it before carrying out work on the system.
- Observe all applicable accident protection and safety regulations for electrical equipment.



- Use a high quality electrical power supply (filtered and regulated).
- Use cables with an operating temperature limit correct for your application.



- Protect the power supply by means of a 300 mA fuse and a switch.
- Do not install the cables near high voltage or high frequency cables. If this cannot be avoided, observe a min. distance of 30 cm.

→ Loosen the 4 screws of the cover to access the electronic board of the device (see Fig. 14).




Fig. 14: Terminal assignment



Make sure the installation is equipotential (power supply - 8041):

- Connect together the various earth spots in the installation to eliminate the potential differences that may occur between two earthes.
- In the housing, connect the power supply cable shield to terminal no. 4 of the electronic board connector (Fig. 15). On a version with stainless steel flow sensor, a second cable is coming from the sensor.
- Connect the negative power supply terminal to the earth to suppress the effects of common mode currents. If this connection cannot be made directly, a 100 nF/50 V capacitor can be connectec between the negative power supply terminal and the earth (marked 1, Fig. 16).
 - If the pipes are made of metal:
 - connect to the same earth the different metallic instruments (valve, pump...) located near the device (marks 2, Fig. 16).
 - If the pipes are made of plastic:
 - insert the metal parts (not provided) in the plastic pipes, upstream and downstream of the device (marked 2, Fig. 16).
 - connect the metal parts to the same earth (Fig. 16).

NOTE

The device is not tight if only one or none of the cable glands is used

- The device is only tight when the cable glands are either wired or sealed. To seal a cable gland, do the following:

- Loosen the nut of the unused cable gland.
- Remove the transparent disk.
- Insert the supplied stopper gasket.
- Screw the nut of the cable gland.

- Loosen the nuts of the cable glands.
- Insert each cable through a nut than through a cable gland.




Fig. 15: Earth connection terminal




Fig. 16: Earthing the device

- Wire the 4-20 mA current output (see 8.3.1).
- Wire the frequency output (see 8.3.2).
- Wire the relay output (see 8.3.3).
- Put the cover of the housing as described in Fig. 17.
- Screw the 4 screws in an alternating pattern.



Fig. 17: Position of the cover of the device

8.3.1. Wiring the 4-20 mA output

The current output of the 8041 can be connected to a PLC or a valve, either in sourcing mode or in sinking mode.

- Set the selector of the electronic board to the sourcing or the sinking position (see [Fig. 18](#) or [Fig. 19](#)).
- Connect the 4-20 mA output in sourcing mode (see [Fig. 18](#)) or in sinking mode (see [Fig. 19](#)).
- Earth the device (see [Fig. 18](#) or [Fig. 19](#)).




Fig. 18: Connection of the current output in sourcing mode




Fig. 19: Connection of the current output in sinking mode

8.3.2. Wiring the frequency output

→ Connect the frequency output:

- to a PLC in PNP or in NPN mode (see [Fig. 20](#) and [Fig. 21](#));
- or to a load such as an electromechanical counter or a relay (see [Fig. 22](#)),
- or to a load such as an electronic counter with its own power supply (see [Fig. 23](#)).

Type 8041
INstallation




Fig. 20: PNP connection of the frequency output to a PLC




Fig. 21: NPN connection of the frequency output to a PLC




Fig. 22: Connection of the frequency output to an electromechanical counter or a relay




Fig. 23: Connection of the frequency output to an electromechanical counter with its own power supply

8.3.3. Wiring the relay output

The relay output operates either in normally open mode (NO) or in normally closed mode (NC), depending on the connection of the load to the electronic board of the device.



→ Protect the relay with a fuse (3 A max.) and, depending on the application, with a circuit breaker.



Do not apply both a dangerous voltage and a safety extra low voltage (SELV) to the relay.

→ Wire the relay output to operate in normally open mode (see Fig. 24) or in normally closed mode (see Fig. 25).

→ Earth the device (see Fig. 24 or Fig. 25).




Fig. 24: Connection of the relay output for a normally open operating

Type 8041

Adjustment and commissioning




Fig. 25: Connection of the relay output for a normally closed operating

9. ADJUSTMENT AND COMMISSIONING

9.1. Safety instructions



DANGER

Risk of injury due to electrical voltage.

- Observe all applicable accident protection and safety regulations for electrical equipment.



WARNING

Risk of injury due to non-conforming operating.

Non-conforming operating could lead to injuries and damage the device and its surroundings.

- The operators in charge of operating must have read and understood the contents of these operating instructions.
- In particular, observe the safety recommendations and intended use.
- The device/installation must only be operated by suitably trained staff.



WARNING

Danger due to non-conforming commissioning.

Non-conforming commissioning can lead to injuries and damage the device and its surroundings.

- Before commissioning, make sure that the staff in charge have read and fully understood the contents of these operating instructions.
- In particular, observe the safety recommendations and intended use.
- The device / the installation must only be commissioned by suitably trained staff.

NOTE

The device may be damaged by the environment

- Protect this device against electromagnetic interference, ultraviolet rays and, when installed outdoors, the effects of the climatic conditions.



When the device is energized and if the cover is open, there is no protection against electric shocks.

9.2. Description of the electronic board

The device has 2 operating modes: the Read mode and the Parameterizing mode. The functions of each mode are summarised in the following table.

Operating mode	Functions
Read	To view: <ul style="list-style-type: none"> ▪ the fluid velocity measured by the device; ▪ the values set for the relay function.
Parameterizing	<ul style="list-style-type: none"> ▪ To calibrate the device. ▪ To set the relay parameters.

The 5 switches, the push-button, the green LED, the red LED and the bargraph are used to set the parameters of the device (see [Fig. 26](#)).

Type 8041

Adjustment and commissioning






Fig. 26: Electronic board of the device

9.3. General diagram of the Read and Parameterizing modes



Type 8041

Adjustment and commissioning



9.4. Selecting the frequency of the main supply

Switch 1 is used to select the frequency of the current provided by the electricity network.

→ Position switch 1 to ON or OFF depending on the frequency of the main supply (see [Fig. 26](#), [chap. 9.2](#), and the following table).

Frequency of the power supplied by the network	Position of switch 1
50 Hz	OFF
60 Hz	ON

9.5. Filter selection

The filter is used to attenuate the fluctuations in the flow indicated by the bargraph and on the current and frequency outputs. The device can operate with or without filter.

→ Position switch 2 (see [Fig. 26](#), [chap. 9.2](#), and the following table) to activate or deactivate the filter feature.

Filter	Position of switch 2
disabled	OFF
enabled	ON

When the filter is enabled, switch 3 is used to select the filter level: slow or fast.

"Slow" filter is used to even out high variations in flow (example: fluid containing air bubbles), see [Fig. 27](#).

"Fast" filter is used to even out low variations in flow (see [Fig. 27](#)).




Fig. 27: Flow filters

→ Position switch 3 to the filter level selected (see [Fig. 26](#), and the following table).

Filter	Position of switch 3
slow (Response time 10 to 90 % = 14 s)	OFF
fast (Response time 10 to 90 % = 5 s)	ON

9.6. Selecting the measurement range

The output signal is proportional to the measured flow velocity. Switches 4 and 5 are used to adjust the measuring range of the device to your application.

→ Position switches 4 and 5 to select the measuring range (see [Fig. 26](#), and the following table).



After the measuring range has been modified, the percentages set for the low and high switching thresholds are applied to the new full scale selected.

Measuring range	Position of switch 4	Position of switch 5
0 to 2 m/s	ON	OFF
0 to 5 m/s	OFF	ON
0 to 10 m/s	OFF	OFF
0 to calibrated full scale (between 2 and 10 m/s)	ON	ON

9.7. Calibrating the flow zero point



→ Calibrate the device on commissioning and after each maintenance task.

- Before calibrating the zero point on commissioning:
 - immerse the measuring element in the fluid for 24 h before calibration.
- Before calibrating the zero point after each maintenance task:
 - immerse the measuring element in the fluid for 1 h before calibration.



→ Before calibration, ensure that the pipe does not contain any air bubbles and that the fluid is not moving.

→ Fill the pipe with fluid.

→ Stop the flow.

→ Calibrate the "zero flow" point (see [Fig. 28](#) and [Fig. 29](#)).




Fig. 28: Calibration of the zero flow point, part 1




Fig. 29: Calibration of the zero flow point, part 2

9.8. Calibrating the full scale

The Fig. 30 and the Fig. 31 show the relation between the measured fluid velocity and the value of the frequency or current provided by the outputs.




Fig. 30: Relation between the measured fluid velocity and the value of the frequency output




Fig. 31: Relation between the measured fluid velocity and the value of the current output

If no predefined measuring range is applicable to your process, the device can be calibrated with the actual max. flow velocity of the application.

The low bound of the measuring range is 0 m/s.

- Position the switches 4 and 5 to ON (see Fig. 26, chap. 9.2).
- Install the device on the pipe as described in chap. 8.
- Allow the fluid to circulate in the pipe at maximum velocity.
- Calibrate the full scale, see Fig. 32 and Fig. 33.




Fig. 32: Calibration of the full scale, part 1




Fig. 33: Calibration of the full scale, part 2

9.9. Setting the parameters of the relay output

The Fig. 34 shows the behaviour of the relay output depending on the parameter settings and the measured velocity.




Fig. 34: Behaviour of the relay output depending on the parameter settings and the measured velocity



The wiring of the relay determines the function of the relay:
Normally Open (NO) or Normally Closed (NC).

The following parameters of the relay output can be set:

- the switching way: window or hysteresis (see chap. [9.9.1](#))
- the value of the low switching threshold, as a percentage of the full scale (see chap. [9.9.2](#))
- the value of the high switching threshold, as a percentage of the full scale (see chap. [9.9.2](#))
- the time delay before switching: from 0 to 100 seconds (see chap. [9.9.3](#)).

9.9.1. Choosing the switching way of the relay output

Two switching ways of the relay are available, window or hysteresis.

In window switching, the state of the relay output is changed whenever one of the thresholds is detected (see [Fig. 35](#) and [Fig. 36](#)).




Fig. 35: Change of state of the relay output in window switching with a relay wired as NO




Fig. 36: Change of state of the relay output in window switching with a relay wired as NC

In hysteresis switching (see [Fig. 37](#) and [Fig. 38](#)), the state of the relay output is changed:

- when both the high threshold is detected and the fluid velocity increases;
- when both the low threshold is detected and the fluid velocity decreases;




Fig. 37: Change of state of the relay output in hysteresis switching with a relay wired as NO

Type 8041

Adjustment and commissioning




Fig. 38: Change of state of the relay output in hysteresis switching with a relay wired as NC

→ Select the way of switching of the relay (see [Fig. 39](#) and [Fig. 40](#)).

Notation convention for the following diagram:




Fig. 39: Choosing the relay switching way, part 1




Fig. 40: Choosing the relay switching way, part 2

9.9.2. Viewing and setting the low and high switching thresholds

The low switching threshold can be set in the range from 0 to the high switching threshold value.

The high switching threshold can be set in the range from the low switching threshold value to 100% of the full scale.

The low and high switching thresholds are set in 2 steps:

- setting the factors of ten;
- setting the units.

→ Viewing and/or setting the low and high switching thresholds (see [Fig. 41](#), [Fig. 42](#) and [Fig. 43](#)).




Fig. 41: Setting the relay switching thresholds, part 1




Fig. 42: Setting the relay switching thresholds, part 2




Fig. 43: Setting the relay switching thresholds, part 3

9.9.3. Viewing and setting the time delay before switching

Switching occurs if one of the thresholds (low, high) is exceeded for a period longer than the set time delay. The time delay applies to both switching thresholds.

The time delay before switching must be set to between 0 and 100 s. If the time delay is equal to 0, switching occurs immediately.

The time delay before switching is set in 2 steps:

- setting the factors of ten for the seconds;
- setting the seconds.

→ Viewing and/or setting the time delay before switching (see [Fig. 44](#), [Fig. 45](#) and [Fig. 46](#)).




Fig. 44: Setting the time delay before relay switching, part 1




Fig. 45: Setting the time delay before relay switching, part 2




Fig. 46: Setting the time delay before relay switching, part 3

10. MAINTENANCE AND TROUBLESHOOTING

10.1. Safety instructions



DANGER

Risk of injury due to high pressure in the installation.

- Stop the circulation of fluid, cut off the pressure and drain the pipe before loosening the process connections.

Risk of injury due to high fluid temperatures.

- Use safety gloves to handle the device.
- Stop the circulation of fluid and drain the pipe before loosening the process connections.

Risk of injury due to the nature of the fluid.

- Respect the prevailing regulations on accident prevention and safety relating to the use of aggressive fluids.

Risk of injury due to electrical voltage.

- Shut down the electrical power source of all the conductors and isolate it before carrying out work on the system.
- Observe all applicable accident protection and safety regulations for electrical equipment.



WARNING

Risk of injury due to non-conforming maintenance.

- Maintenance must only be carried out by qualified and skilled staff with the appropriate tools.
- Guarantee a set or controlled restarting of the process subsequent to any intervention.

10.2. Cleaning the device

NOTE

The device may be damaged by the cleaning product.

- Clean the device with a cloth dampened with water or a detergent compatible with the materials the device is made of.
- Do not use any abrasive acting materials.

10.3. Cleaning the electrodes

NOTE

Dirt on the electrodes may cause measurement errors.

- Regularly clean the wetted parts.
- Rinse the electrodes after cleaning.

10.4. Replacing the seal on a device with G2" nut

NOTE

Do not scratch the seal groove.




Fig. 47: Dismounting the device and location of the seal

- Loosen the nut of the device (mark 2).
- Remove the device from the fitting (mark 1).
- Remove the seal from the groove.
- Clean the seal groove.
- Insert the new O-ring in the groove (see chap. 11).
- Insert the device into the fitting.
- Tighten the nut (mark 2) by hand on the device.

10.5. If you encounter problems



DANGER

Risk of injury due to high pressure in the installation.

- Stop the circulation of fluid and cut off the pressure before loosening the process connections.

Risk of injury due to electrical voltage.

- Shut down the electrical power source of all the conductors and isolate it before carrying out work on the system.
- Observe all applicable accident protection and safety regulations for electrical equipment.

Risk of injury due to high fluid temperatures.

- Use safety gloves to handle the device.
- Stop the circulation of fluid and drain the pipe before loosening the process connections.

Risk of injury due to the nature of the fluid.

- Respect the prevailing regulations on accident prevention and safety relating to the use of aggressive fluids.

Problem	Bargraph state	Red LED state	Green LED state	Current or frequency output state	Meaning / Cause	Recommended action
The device does not respond	OFF	Flashes once briefly every 2 s	Flashes once every second	22 mA and 256 Hz	Measuring range exceeded by more than 20%	<ul style="list-style-type: none"> → Clear the error by briefly pressing the push-button. → Consult the graphs (see chap. 8.2.1).
The device does not respond	OFF	Flashes twice briefly every 2 s	Flashes once every second	22 mA and 0 Hz	The flow zero point calibration failed.	<ul style="list-style-type: none"> → Clear the error by briefly pressing the push-button. → Check upstream/downstream distances (see chap. 8.2.1). → Restart the calibration (see chap. 9.7). → If the error persists, contact your Bürkert retailer.
The device does not respond	OFF	Flashes 3 times briefly every 2 s	Flashes once every second	22 mA and 0 Hz	The device is out of service	<ul style="list-style-type: none"> → Contact your Bürkert retailer.
The device does not respond	OFF	Flashes 4 times briefly every 2 s	Flashes once every second	22 mA and 0 Hz	The full scale calibration failed because the fluid velocity < 2 m/s	<ul style="list-style-type: none"> → Clear the error by briefly pressing the push-button. → Check the fluid velocity. → Restart the calibration of the full scale (see chap. 9.8).

Problem	Bargraph state	Red LED state	Green LED state	Current or frequency output state	Meaning / Cause	Recommended action
The device does not respond	OFF	Flashes 5 times briefly every 2 s	Flashes once every second	22 mA and 0 Hz	The calibration of the full scale failed because the fluid velocity > 10 m/s.	<ul style="list-style-type: none"> → Clear the error by briefly pressing the push-button. → Check the fluid velocity. → Restart the calibration of the full scale (see chap. 9.8).
The sensor does not work	OFF	OFF	OFF	0 mA and 0 Hz	The device is not connected.	→ Connect the device.
					The fuse of the installation is in a bad condition	→ Replace the fuse.
					The switch of the installation is set to OFF	→ Position the installation switch to ON.
				-	The power supply has been wrong connected to the + and - terminals	→ Check the wiring (see chap. 8.3.1, 8.3.2, 8.3.3).
				Flashes irregularly or is off	0 mA and 0 Hz	The power supply is not stable.
			OFF	0 mA and 0 Hz	The device is out of service	→ Return the device to your Bürkert retailer.
Incorrect flow measurement.	-	OFF	Flashes once every second	-	The K factor has not been correctly calculated.	→ Recalculate the K factor (see chap. 6.7).
	All the LEDs are ON	OFF	Flashes once every second	20 mA and 240 Hz	Measuring range exceeded by less than 20%.	→ Select the higher measuring range (see chap. 9.6)

Problem	Bargraph state	Red LED state	Green LED state	Current or frequency output state	Meaning / Cause	Recommended action
The flow rate measurements are not stable	Unstable	OFF	Flashes once every second	> 4 mA and > 0 Hz	The electrodes are dirty.	→ Clean the electrodes (see chap. 10.3).
					The electrodes are not in contact with the fluid.	→ Make sure the electrodes are always in contact with the fluid
					Air bubbles appear in the fluid.	→ Respect the mounting recommendations (see chap. 8.2). → Select the "slow" filter (see chap. 9.5).
					The flow sensor has not been immersed for 24 h before calibration of the "flow zero" point.	→ Respect the calibration procedure (see chap. 9.7).
					The flow rate fluctuations are very important.	→ Select the "slow" filter (see chap. 9.5).
					Upstream-downstream connection has not been correctly done.	→ Respect the mounting recommendations (see chap. 8.2).
The device transmits no current or no frequency at all.	shows a value	OFF	Flashes once every second	0 mA and/or 0 Hz	The position of the sink/source selector is not correct.	→ Correctly position the sink/source selector (see chap. 8.3.1).
					The outputs are not correctly wired.	→ Check the wiring of the outputs (see chap. 8.3.1, 8.3.2, 8.3.3).
The sensor does not measure a nil flow rate.	Lit	OFF	Flashes once every second	> 4 mA and > 0 Hz	The calibration of the flow zero point has not been correctly done.	→ Calibrate again (see chap. 9.7).

11. SPARE PARTS AND ACCESSORIES



ATTENTION

Risk of injury and/or damage caused by the use of unsuitable parts.

Incorrect accessories and unsuitable replacement parts may cause injuries and damage the device and the surrounding area.

- Use only original accessories and original spare parts from Bürkert.

Spare parts	Order code
Set of: <ul style="list-style-type: none"> - 2 M20x1.5 cable glands - 2 neoprene flat seals for cable glands or a screw plugs - 2 M20x1.5 screw plugs - 2 multiway seals 2x6 mm 	449755
Set of: <ul style="list-style-type: none"> - 2 M20x1,5 / NPT 1/2" reductions - 2 neoprene flat seals for cable glands - 2 M20x1.5 screw plugs 	551782

Spare parts	Order code
Set of: <ul style="list-style-type: none"> - 1 stopper gasket for an M20x1.5 cable gland - 1 multiway seal, 2x6 mm, for cable gland - 1 green FKM seal for the flow sensor of a 8041 with G2" nut - 1 mounting instruction sheet 	558102
Snap ring	619205
PPA nut	440229
PC nut	619204
Set of: <ul style="list-style-type: none"> - 1 green FKM seal - 1 black EPDM seal 	552111
Relay connection kit with: <ul style="list-style-type: none"> - Terminal block - 1 protective cap - 1 cable clip - 1 mounting instruction sheet 	552812
EPDM seal with FDA agreement (for a 8041 with a clamp connection)	730837
FEP seal with FDA agreement (for a 8041 with a clamp connection)	730839
Clamp collar	731164

Spare parts	Order code
Set of:	565384
<ul style="list-style-type: none"> - 1 stopper gasket for an M20 x 1,5 cable gland - 1 multi-way seal, 2 x 6 mm, for a cable gland 	

12. PACKAGING, TRANSPORT

ATTENTION

Damage due to transport

Transport may damage an insufficiently protected device.

- Transport the device in shock-resistant packaging and away from humidity and dirt.
- Do not expose the device to temperatures outside the admissible storage temperature range.
- Protect the electrical interfaces using protective plugs.

13. STORAGE

ATTENTION

Poor storage can damage the device.

- Store the device in a dry place away from dust.
- Storage temperature: -20...+60 °C.
- Humidity: < 80%, non condensated.

14. DISPOSAL OF THE DEVICE

→ Dispose of the device and its packaging in an environmentally friendly way.

ATTENTION

Damage to the environment caused by products contaminated by fluids.

- Keep to the existing provisions on the subject of waste disposal and environmental protection.



Note:

Comply with the national and/or local regulations which concern the area of waste disposal.

www.burkert.com